

Winnebago Safety Harness Location on a Paseo Van:

- 1) Remove doors from the refrigerator.
 - a) Undo top bolt from both doors.
 - b) Gently pull the door away and up from the refrigerator.
- 2) Remove black frame plugs (6) from around the refrigerator frame.
- 3) Unscrew all frame screws (6)
- 4) Remove covers from bench next to table (on the refrigerator side of the van).



- 5) Open bench and unscrew the restraining bolt.



- 6) Put a towel or a piece of cardboard on the floor in front of the refrigerator (to prevent scratching the galley floor).
- 7) Gently pull out the refrigerator from the cabinet and place it onto the van floor.
- 8) Reverse steps for installation.