

# Service Memo

**To:** Service Personnel

**Re:** Door panel installation

---

The door on your Nova Kool unit is designed for the installation of a door panel of up to ¼ inch (6mm) thick. In many cases the door will have a panel pre installed. Nova Kool offer Black or White plastic and Stainless steel.

Many of the OEM'S (original equipment manufactures, boat, RV, truck builders) install a panel in the door to match the interior of the space the Nova Kool unit is being installed.

To change a panel or install a different panel the following is recommended:

1. empty the door of any food
2. remove the hinge pin from the top of the door on the hinged side, this can be done with a 7/16 wrench and is a standard c/w thread
3. with the top hinge pin removed, pull the top of the door clear of the hinge
4. gently lift the door off the bottom hinge pin so it is free of the unit
5. turn the door upside down and rest it on some carpet or soft material so as not to mark the frame
6. remove the two screws from the bottom of the door, and pull the plastic base of the door away from the door. The door gasket will remain attached to this piece so gently push it away from the channel on the front of the door
7. install your panel by sliding the panel into the side slots. If your panel is thinner than 1/4 inch (6mm) add some cardboard between the panel and the front of the door skin. This will push the panel out so it is tight to the channel so it will not rattle and improve the finished look
8. With the panel installed in the door, place the bottom piece of channel back onto the bottom of the door and install the two screws back into the holes they came out of
9. If you need to know the size of the panel for a specific fridge, view the spec sheet for that fridge on the web
10. before returning the door to the hinge pins double check to make sure the gasket on the bottom of the door is in the channel by gently pushing it on the flat section of the gasket into the frame of the door
11. place the door back on the bottom hinge pin and put the top pin back in place

*For more information contact Nova Kool @604-523-6515 pacific standard time*