



Front View

- 1) Frame 38 c/w frame screw, frame gasket
- 2) Frame 23 c/w frame screw, frame gasket
- 3) Door 38 c/w bottle bar, door gasket 38, door pad, panel (black or white) *Not Shown*, door rod
- 4) Door 23 c/w door gasket 23, door pad, panel (black or white) *Not Shown*
- 5) Hinge Assembly c/w hinge bearing, hinge left, hinge right, hinge pin (4), hinge screw (24)
- 6) Thumb Latch (2) c/w thumb latch, latch pin, latch spacer
- 7) Shelf 23
- 8) Shelf 38
- 9) Thermostat Assembly c/w knob, case, wire 45 (grey)
- 10) Evaporator 23 (3) c/w capillary tube, suction line, armaflex
- 11) Evaporator 23 c/w suction line, armaflex
- 12) Drip Tray 38
- 13) Latch 75 (2) c/w male & female ends, screws (4)
- 14) Crisper Shelf 38 c/w crisper support bracket & aluminum bar
- 15) Crisper 38
- 16) Accessory Bag c/w ice cube tray, manual, mounting hole plugs (4)

Back View

- 1) Condenser 23 c/w mounting clips & screws
- 2) Pipe Insulation
- 3) Base 23 c/w screws
- 4) bd3.5f Compressor c/w rubber feet (4), compressor clip (4)
- 5) Fridge Drier
- 6) Electronic AC/DC* c/w red wire 11, black wire 11
- 7) AC Receptacle c/w fuse 4, wire harness,
- 8) AC Cord 115 optional 220 *not shown*
- 9) Cabinet 23
- 10) Cabinet 38
- 11) Fan Assembly c/w fan12, fan bracket
- 12) Speed Resistor (Optional) No resistor=low speed, black resistor=medium speed, red resistor=high speed
- 13) Top Hat Bracket (2) *not shown*

Base Expanded View

Notes:

* DC models electronic 2000 replaces electronic AC/DC